

PG500 Installation Manual

All Rights Reserved. Copyright © 2007, RKC INSTRUMENT INC.

IMR02F01-E4

Thank you for purchasing this RKC product. In order to achieve maximum performance and ensure proper operation of your new instrument, carefully read all the instructions in this manual. Please place the manual in a convenient location for easy reference.

This manual describes the mounting, wiring and specifications.

For the operations, refer to **PG500 Operation Manual (IMR02F02-E□)**.
For the communication (Optional), refer to the **PG500 Communication Quick Instruction Manual (IMR02F03-E□)** or the separate **PG500 Communication Instruction Manual (IMR02F04-E□)**.
The manuals can be downloaded from the official RKC website:
http://www.rkcinst.com/english/manual_load.htm.

Accessories check

PG500 Installation Manual (IMR02F01-E4)	1
PG500 Operation Manual (IMR02F02-E□)	1
PG500 Communication Quick Instruction Manual (IMR02F03-E□) *	1
Mounting brackets (with screw)	2
Unit seal (SAP-368)	1

* Only PG500 provided with the communication function

Safety precautions



WARNING

- An external protection device must be installed if failure of this instrument could result in damage to the instrument, equipment or injury to personnel.
- All wiring must be completed before power is turned on to prevent electric shock, fire or damage to instrument and equipment.
- This instrument must be used in accordance with the specifications to prevent fire or damage to instrument and equipment.
- This instrument is not intended for use in locations subject to flammable or explosive gases.
- Do not touch high-voltage connections such as power supply terminals, etc. to avoid electric shock.
- RKC is not responsible if this instrument is repaired, modified or disassembled by other than factory-approved personnel. Malfunction can occur and warranty is void under these conditions.

CAUTION

- This product is intended for use with industrial machines, test and measuring equipment. (It is not designed for use with medical equipment and nuclear energy.)
- This is a Class A instrument. In a domestic environment, this instrument may cause radio interference, in which case the user may be required to take adequate measures.
- This instrument is protected from electric shock by reinforced insulation. Provide reinforced insulation between the wire for the input signal and the wires for instrument power supply, source of power and loads.
- Be sure to provide an appropriate surge control circuit respectively for the following:
 - If input/output or signal lines within the building are longer than 30 meters.
 - If input/output or signal lines leave the building, regardless the length.
- This instrument is designed for installation in an enclosed instrumentation panel. All high-voltage connections such as power supply terminals must be enclosed in the instrumentation panel to avoid electric shock by operating personnel.
- All precautions described in this manual should be taken to avoid damage to the instrument or equipment.
- All wiring must be in accordance with local codes and regulations.
- To prevent instrument damage or failure, protect the power line and the input/output lines from high currents with a protection device such as fuse, circuit breaker, etc.
- Prevent metal fragments or lead wire scraps from falling inside instrument case to avoid electric shock, fire or malfunction.
- Tighten each terminal screw to the specified torque found in the manual to avoid electric shock, fire or malfunction.
- For proper operation of this instrument, provide adequate ventilation for heat dissipation.
- Do not connect wires to unused terminals as this will interfere with proper operation of the instrument.
- Turn off the power supply before cleaning the instrument.
- Do not use a volatile solvent such as paint thinner to clean the instrument. Deformation or discoloration will occur. Use a soft, dry cloth to remove stains from the instrument.
- To avoid damage to instrument display, do not rub with an abrasive material or push front panel with a hard object.

NOTICE

- This manual assumes that the reader has a fundamental knowledge of the principles of electricity, process control, computer technology and communications.
- The figures, diagrams and numeric values used in this manual are only for purpose of illustration.
- RKC is not responsible for any damage or injury that is caused as a result of using this instrument, instrument failure or indirect damage.
- RKC is not responsible for any damage and/or injury resulting from the use of instruments made by imitating this instrument.
- Periodic maintenance is required for safe and proper operation of this instrument. Some components have a limited service life, or characteristics that change over time.
- Every effort has been made to ensure accuracy of all information contained herein. RKC makes no warranty expressed or implied, with respect to the accuracy of the information. The information in this manual is subject to change without prior notice.
- No portion of this document may be reprinted, modified, copied, transmitted, digitized, stored, processed or retrieved through any mechanical, electronic, optical or other means without prior written approval from RKC.

1. MOUNTING




WARNING

To prevent electric shock or instrument failure, always turn off the power before mounting or removing the instrument.

1.1 Mounting Cautions

- (1) This instrument is intended to be used under the following environmental conditions. (IEC61010-1) [OVERVOLTAGE CATEGORY II, POLLUTION DEGREE 2]
 - Allowable ambient temperature: -10 to +50 °C
 - Allowable ambient humidity: 5 to 95 % RH (Absolute humidity: MAX. W. C 29.3 g/m³ dry air at 101.3 kPa)
- (2) Use this instrument under the following environment conditions.
 - Installation environment conditions: Indoor use, Altitude up to 2000 m
 - (3) Avoid the following conditions when selecting the mounting location:
 - Rapid changes in ambient temperature which may cause condensation.
 - Corrosive or inflammable gases.
 - Direct vibration or shock to the mainframe.
 - Water, oil, chemicals, vapor or steam splashes.
 - Excessive dust, salt or iron particles.
 - Excessive induction noise, static electricity, magnetic fields or noise.
 - Direct air flow from an air conditioner.
 - Exposure to direct sunlight.
 - Excessive heat accumulation.
- (4) Mount this instrument in the panel considering the following conditions:
 - Ensure at least 50 mm space on top and bottom of the instrument for maintenance and environmental reasons.
 - Do not mount this instrument directly above equipment that generates large amount of heat (heaters, transformers, semi-conductor functional devices, large-wattage resistors.)
 - If the ambient temperature rises above 50 °C, cool this instrument with a forced air fan, cooler, or the like. Cooled air should not blow directly on this instrument.
 - In order to improve safety and the immunity to withstand noise, mount this instrument as far away as possible from high voltage equipment, power lines, and rotating machinery.
 - High voltage equipment: Do not mount within the same panel.
 - Power lines: Separate at least 200 mm.
 - Rotating machinery: Separate as far as possible.
 - Mount this instrument in the horizontal direction for panel. If you did installation except a horizontal direction, this causes malfunction.
 - If this instrument is permanently connected to equipment, it is important to include a switch or circuit-breaker into the installation. This should be in close proximity to the equipment and within easy reach of the operator. It should be marked as the disconnecting device for the equipment.

1.2 Dimensions




- *1 Case rubber packing
- *2 When cutting out each mounting hole through a panel for individual mounting, observe that there is no burr or distortion along the panel cutout surface, or there is no bend on the panel surface. If so, the water resistant characteristics may worsen.
- *3 Remove the case rubber packing. Because of closely mounting the PG500s, protection will be compromised and not meet IP66 (NEMA 4X) by close mounting.

1.3 Procedures of Mounting and Removing

Mounting procedures


1. Prepare the panel cutout as specified in 1.2 Dimensions.
2. Insert the instrument through the panel cutout.
3. Insert the mounting bracket into the mounting groove of the instrument. (Fig. 1)
4. Push the mounting bracket forward until the bracket is firmly secured to the panel. (Fig. 2)
5. Only turn one full revolution after the screw touches the panel. (Fig. 3)
6. The other mounting bracket should be installed the same way described in 3. to 5.



The front of the instrument conforms to IP66 (NEMA4X) when mounted on the panel. For effective waterproof/dustproof, the rubber packing must be securely placed between instrument and panel without any gap. If rubber packing is damaged, please contact RKC sales office or the agent.

Removing procedures

1. Turn the power OFF.
2. Remove the wiring.
3. Loosen the screw of the mounting bracket.
4. Lift the latch of the mounting bracket (①), then pull the mounting bracket (②) to remove it from the case. (Fig. 4)
5. Use long-nose pliers to remove mounting brackets from the instrument that is installed in a narrow place or installed tightly in a vertical position. (Fig. 5)
6. The other mounting bracket should be removed in the same way as described in 3. and 4.
7. Pull out the instrument from the mounting cutout while holding the front panel frame of this instrument. (Fig. 5)



2. WIRING




WARNING

To prevent electric shock or instrument failure, do not turn on the power until all wiring is completed. Make sure that the wiring is correct before applying power to the instrument.





2.1 Wiring Cautions

- Use a shielded cable for connection with the pressure sensor.
- To avoid noise induction, keep communication signal wire away from instrument power line, load lines and power lines of other electric equipment.
- If there is electrical noise in the vicinity of the instrument that could affect operation, use a noise filter.
 - Shorten the distance between the twisted power supply wire pitches to achieve the most effective noise reduction.
 - Always install the noise filter on a grounded panel. Minimize the wiring distance between the noise filter output and the instrument power supply terminals to achieve the most effective noise reduction.
 - Do not connect fuses or switches to the noise filter output wiring as this will reduce the effectiveness of the noise filter.
- About five seconds are required as preparation time for contact output every time the instrument is turned on. Use a delay relay when the output line is used for an external interlock circuit.
- Power supply wiring must be twisted and have a low voltage drop.
- For an instrument with 24 V power supply, supply power from a SELV circuit.
- A suitable power supply should be considered in the end-use equipment. The power supply must be in compliance with a limited-energy circuits (maximum available current of 8 A).
- This instrument is not furnished with a power supply switch or fuse. Therefore, if a fuse or power supply switch is required, install close to the instrument. Recommended fuse rating: Rated voltage 250 V, Rated current 1 A Fuse type: Time-lag fuse
- Use the solderless terminal appropriate to the screw size.
 - Screw size: M3 × 7 (with 5.8 × 5.8 square washer)
 - Applicable wire: Solid/twisted wire of 0.25 to 1.65 mm²
 - Specified dimension: Refer to Fig. 6
 - Recommended tightening torque: 0.4 N·m (4 kgf·cm)
 - Specified solderless terminals:
 - Manufactured by J.S.T MFG CO., LTD.
 - Circular terminal with isolation V1.25-MS3
- Make sure that the any wiring such as solderless terminal is not in contact with the adjoining terminals.

- If solderless terminal lugs other than those in not specified dimensions are used, terminal screws may not be tightened. In such a case, bend each solderless terminal lug in advance and then conduct wiring. If the terminal screw is forcibly tightened, it may be damaged.
- Up to two solderless terminal lugs can be connected to one terminal screw. However, in this case, reinforced insulation cannot be used.
- Caution for the terminal cover usage: If each solderless terminal lug touches the terminal cover, remove each projection from the terminal cover by manually bending it in front and in rear until broken.




2.2 Terminal Configuration



Input/Output Isolation:
 : Isolated from each other circuit blocks.
 : Not isolated between inputs (or outputs).

Power supply	Transmission output (AO) Calibration output
Pressure sensor input	Alarm 1 output (ALM1)
Digital input 1 (DI1)	Alarm 2 output (ALM2)
Digital input 2 (DI2)	Alarm 3 output (ALM3)
Communication	Alarm 4 output (ALM4)

Wiring example



Pressure Indicator **PG500** Communication Quick Instruction Manual

All Rights Reserved, Copyright © 2007, RKC INSTRUMENT INC. **IMR02F03-E3**

Thank you for purchasing this RKC product. In order to achieve maximum performance and ensure proper operation of your new instrument, carefully read all the instructions in this manual. Please place the manual in a convenient location for easy reference. This manual describes the connection method with host computer, communication parameters and communication data of the PG500.

For detailed host communication such as protocol description, refer to the **PG500 Communication Instruction Manual (IMR02F04-E0)**. The manual can be downloaded from the official RKC website: http://www.rkcinst.com/english/manual_load.htm.

1. CONNECTION TO HOST COMPUTER



WARNING

To prevent electric shock or instrument failure, turn off the power before connecting or disconnecting the instrument and peripheral equipment.


The cable and termination resistor (s) must be provided by the customer.

1.1 RS-485

■ Communication terminal number and signal details


Terminal No.	Signal name	Symbol
25	Signal ground	SG
26	Send/Receive data	T/R (A)
27	Send/Receive data	T/R (B)

■ When the interface of host computer (Master) is RS-485



■ When the host computer (Master) has a USB connector

Connect the USB communication converter between the host computer and the PG500.




For the COM-K, refer to the **COM-K Instruction Manual (IMR01Z01-E0)**.

1.2 RS-422A

■ Communication terminal number and signal details


Terminal No.	Signal name	Symbol	Terminal No.	Signal name	Symbol
25	Signal ground	SG	28	Receive data	R (A)
26	Send data	T (A)	29	Receive data	R (B)
27	Send data	T (B)			

■ When the interface of host computer (Master) is RS-422A



■ When the host computer (Master) has a USB connector

Connect the USB communication converter between the host computer and the PG500.



For the COM-K, refer to the **COM-K Instruction Manual (IMR01Z01-E0)**.

2. SETTING

To establish communication parameters between host computer and PG500, it is necessary to set the following parameters.

When all communication parameter settings have been completed, turn the power off and then on to make the new set values take effect.

This section describes the parameters to need setting for communication. For the mode/parameters transfer and data setting, refer to the **PG500 Operation Manual (IMR02F02-E0)**.

■ Description of each parameters

● Engineering mode F60

Symbol	Name	Data range	Description	Factory set value
$\overline{Cn}P$ (CMP)	Communication protocol	0: RKC communication 1: Modbus	Use to select a protocol of communication function.	0

● Setup setting mode

Symbol	Name	Data range	Description	Factory set value
\overline{Add} (Add)	Device address (Slave address)	0 to 99 Maximum connections: Up to 31 instruments	Do not use the same device address for more than one instrument in multi-drop connection. Each instrument must have a unique address in multi-drop connection. In Modbus communication, communication is not possible when the address is 0.	0
\overline{bPS} (bPS)	Communication speed	1.2: 1200 bps 2.4: 2400 bps 4.8: 4800 bps 9.6: 9600 bps 19.2: 19200 bps 38.4: 38400 bps	Set the same communication speed for both the PG500 (slave) and the host computer (master).	9.6

Symbol	Name	Data range	Description	Factory set value
$\overline{bI} \overline{\Gamma}$ (bIT)	Data bit configuration	Refer to Data bit configuration table	Set the same data bit configuration for both the PG500 (slave) and the host computer (master).	8n1
$\overline{In} \overline{\Gamma}$ (InT)	Interval time	0 to 250 ms	The interval time for the PG500 should be set to provide a time for host computer to finish sending all data including stop bit and to switch the line to receive status for the host.	10

Data bit configuration table

Set value	Data bit	Parity bit	Stop bit	Set value	Data bit	Parity bit	Stop bit
$\overline{Bn} \overline{1}$	8	Without	1	$\overline{7n} \overline{1} *$	7	Without	1
$\overline{Bn} \overline{2}$	8	Without	2	$\overline{7n} \overline{2} *$	7	Without	2
$\overline{BE} \overline{1}$	8	Even	1	$\overline{7E} \overline{1} *$	7	Even	1
$\overline{BE} \overline{2}$	8	Even	2	$\overline{7E} \overline{2} *$	7	Even	2
$\overline{Bo} \overline{1}$	8	Odd	1	$\overline{7o} \overline{1} *$	7	Odd	1
$\overline{Bo} \overline{2}$	8	Odd	2	$\overline{7o} \overline{2} *$	7	Odd	2

* When the Modbus communication protocol selected, this setting becomes invalid.

Interval time:

The interval time for the PG500 should be set to provide a time for host computer to finish sending all data including stop bit and to switch the line to receive status for the host. If the interval time between the two is too short, the PG500 may send data before the host computer is ready to receive it. In this case, communication transmission cannot be conducted correctly.

3. COMMUNICATION REQUIREMENTS

■ Processing times during data send/receive

When the host computer is using either the polling or selecting procedure for communication, the following processing times are required for PG500 to send data:

- Response wait time after PG500 sends BCC in polling procedure
- Response wait time after PG500 sends ACK or NAK in selecting procedure

Response send time is time when interval time is set at 0 ms.

RKC communication (Polling procedure)

Procedure details	Time
Response send time after PG500 receives ENQ	3 ms max.
Response send time after PG500 receives ACK	3 ms max.
Response send time after PG500 receives NAK	3 ms max.
Response send time after PG500 sends BCC	1 ms max.

RKC communication (Selecting procedure)

Procedure details	Time
Response send time after PG500 receives BCC	34 ms max.
Response wait time after PG500 sends ACK	1 ms max.
Response wait time after PG500 sends NAK	1 ms max.


Modbus

Procedure details	Time
Read holding registers [03H] Response send time after the slave receives the query message (When 125 registers are collectively read)	360 ms max.
Preset single register [06H] Response send time after the slave receives the query message	25 ms max.
Diagnostics (loopback test) [08H] Response send time after the slave receives the query message	15 ms max.
Preset multiple registers [10H] Response send time after the slave receives the query message (When 123 registers are collectively write)	360 ms max.


■ RS-485 (2-wire system) send/receive timing (RKC communication)

RS-485 communication is conducted through two wires, therefore the transmission and reception of data requires precise timing.

Polling procedure



Selecting procedure



To switch the host computer from transmission to reception, send data must be on line.

The following processing times are required for the PG500 to process data.
- In Polling procedure, Response wait time after the PG500 sends BCC
- In Selecting procedure, Response wait time after the PG500 sends ACK or NAK

■ RS-422A/RS-485 fail-safe

A transmission error may occur with the transmission line disconnected, shorted or set to the high-impedance state. In order to prevent the above error, it is recommended that the fail-safe function be provided on the receiver side of the host computer. The fail-safe function can prevent a framing error from its occurrence by making the receiver output stable to the MARK (1) when the transmission line is in the high-impedance state.

■ Modbus data processing precautions

- The numeric range of data used in Modbus protocol is 0000H to FFFFH. Only the set value within the setting range is effective.
- FFFFH represents -1.
- Data with decimal point is treated as data without decimal point on the Modbus protocol.
- If data (holding register) exceeding the accessible address range is accessed, an error response message is returned.
- Read data of unused item is a default value.
- Any attempt to write to an unused item is not processed as an error. Data can not be written into an unused item.
- If data range or address error occurs during data writing (Write Action), it is not processed as an error. Normal data is written in data register but data with error is not written; therefore, it is recommended to confirm data of changed items after the data setting.
- An attribute of the item for functions which are not in the indicator is RO (read only). If read action to this item is performed, the read data will be "0." If write action to this item is performed, no error message is indicated and no data is written.
- Commands should be sent at time intervals of 30 bits after the master receives the response message.
- Error code


Problem	Possible cause	Solution
Error code 1	Function cod error (Specifying nonexistent function code)	Confirm the function code
Error code 2	When the mismatched address is specified	Confirm the address of holding register
Error code 3	When the specified number of data items in the query message exceeds the maximum number of data items available	Confirm the setting data
Error code 4	Self-diagnostic error	Turn off the power to the instrument. If the same error occurs when the power is turned back on, please contact RKC sales office or the agent.

4. COMMUNICATION DATA LIST

The communication data map shows data which can be used for communication between the host computer and PG500.

Explanation of data map items

- Modbus register address
HEX: Hexadecimal DEC: Decimal
- Attribute (A method of how communication data items are read or written when viewed from the host computer is described)
RO: Only reading data is possible (Host computer ← PG500)
R/W: Reading and writing data is possible (Host computer ↔ PG500)
- Data



Name	RKC Identifier	Modbus register address		Attribute	Data range	Factory set value
		HEX	DEC			
Model code	ID	—	—	RO	Model character code (32-digit)	—
ROM version monitor	VR	—	—	RO	Version of ROM built-in the instrument (9-digit)	—
Measured value (PV)	M1	00E0	224	RO	Pressure display low to Pressure display high	—
Burnout state monitor	B1	00E1	225	RO	0: OFF 1: ON	—
Alarm 1 state monitor	AA	00E2	226	RO	0: OFF 1: ON	—
Alarm 2 state monitor	AB	00E3	227	RO	—	—
Alarm 3 state monitor	AC	00E4	228	RO	—	—
Alarm 4 state monitor	AD	00E5	229	RO	—	—
Unused	—	00E6	230	—	—	—
Unused	—	00E7	231	—	—	—
Peak hold monitor	HP	00E8	232	RO	Pressure display low to Pressure display high	—
Bottom hold monitor	HQ	00E9	233	RO	At input break: Display range limit	—


PG500 Operation Manual

All Rights Reserved. Copyright © 2007, RKC INSTRUMENT INC. **IMR02F02-E3**
 Thank you for purchasing this RKC product. In order to achieve maximum performance and ensure proper operation of your new instrument, carefully read all the instructions in this manual. Please place the manual in a convenient location for easy reference.
 This manual describes the operation method of the PG500.

For the installation, the parts description, the specifications and the communication function (Optional), please read if necessary the following separate manuals.
 • PG500 Installation Manual (IMR02F01-E□): Enclosed with PG500
 • PG500 Communication Quick Instruction Manual (IMR02F03-E□): Enclosed with PG500 *
 • PG500 Communication Instruction Manual (IMR02F04-E□): Separate volumes
 * Only PG500 provided with the communication function.

The manuals can be downloaded from the official RKC website:
http://www.rkcinst.com/english/manual_load.htm.

1. HANDLING PROCEDURES




2. CHANGING DATA SETTINGS

- To store a new value for the parameter, always press the SET key.
- After a new value is displayed on the display by using UP and DOWN keys, if no key operation is performed within 1 minute without pressing SET key, this instrument returns to the Measured value (PV) screen and the set value will not be changed.


Example: Changing the alarm 1 set value (AL1) to 20 MPa

1. Select the Alarm 1 set value (AL1) of parameter setting mode




2. Change the Alarm 1 set value (AL1) to 20 MPa

Pressing the -MONI key displays the data display. The high-lighted digit indicates which digit can be set.




3. Store the Alarm 1 set value (AL1)



Other data can also be set by the same procedures as described in steps 1 to 3.

3. TRANSFER TO EACH MODE AND PARAMETER

- This instrument return to Measured value (PV) screen, if key operation within 1 minute is not performed.
- Any parameter which is not used in the PG500 will not be displayed except for parameters in engineering mode.



4. PARAMETER LIST

4.1 Monitor Mode

Symbol	Name	Data range	Description
—	Measured value (PV)	Pressure display low to Pressure display high	Display the Measured value (PV).
PHLd (PHLd)	Peak hold monitor *	Pressure display low to Pressure display high	Display the maximum value of Measured value (PV).
bHLd (bHLd)	Bottom hold monitor *	At input break: Display range limit	Display the minimum value of Measured value (PV).

* The hold reset function can be executed by Hold reset (HLdr) in parameter setting mode and Digital input 2 (DI2, terminal Nos. 13 and 15). Reset also takes place when the power is turned off, or when the set value of Input type (InP), Gain setting (GAI n), Display unit (UnI r), Input decimal point position (PGdP) or Linearizing type (LI nS) is changed.

4.2 Setup Setting Mode


Symbol	Name	Data range	Description	Factory set value
InP (InP)	Input type	0 to 4 Refer to Input type and factory set value table	Use to select the input type.	Based on model code.
GAI n (GAI n)	Gain setting	0.500 to 4.000 mV/V or 0.5000 to 1.9999 mV/V Varies with the setting of the Gain setting decimal point position.	Use to set the gain of pressure sensor. CZ-100P/CZ-200P: Refer to Gain setting and linearizing type	Refer to Input type and factory set value table
UnI r (UnI r)	Display unit	0: Kg/cm ² 2: bar 1: MPa 3: psi	Use to select the display unit for input.	1
PGdP (PGdP)	Input decimal point position	0: No decimal place 1: One decimal place 2: Two decimal places 3: Three decimal places	Use to select the decimal point position of the input display value.	0
SCH (SCH)	Pressure display high	Pressure display low to 19999 Varies with the setting of the Input decimal point position.	Use to set the high limit of the pressure display range.	50
SCL (SCL)	Pressure display low	0 to Pressure display high Varies with the setting of the Input decimal point position.	Use to set the low limit of the pressure display range.	0
LI nS (LI nS)	Linearizing type	0 to 20 Resistance for sensitivity adjustment built-in pressure sensor: Use a factory set value of "0."	Use to set the linearizing type of our CZ-100P/CZ-200P. CZ-100P/CZ-200P: Refer to Gain setting and linearizing type	0

Input type and factory set value table

Set value	Input type	Factory set value of gain setting (mV/V)
0	Our CZ-100P/CZ-200P (Standard)	1.500
1	Our CZ-100P/CZ-200P (Explosionproof)	1.500
2	Our CZ-100P/CZ-200P (Standard) [Loose nut: 0.0 to 0.5 MPa, Fixed nut: 0 to 5 MPa]	0.650
3	Our CZ-100P/CZ-200P (Explosionproof) [Loose nut: 0.0 to 0.5 MPa, Fixed nut: 0 to 5 MPa]	0.650
4	3.33 mV/V output type (Pressure sensor made by other companies)	3.330

Gain setting and linearizing type (Only our pressure sensor CZ-100P/CZ-200P)

Set the rated output value (mV/V) and the linearizing type symbol to Gain setting (GAI n) and linearizing type (LI nS) engraved on the rated nameplate attached to the pressure sensor housing.



1.234 C
 linearizing type symbol
 Set it to linearizing type (LI nS) by refer to the linearizing type symbol table.
 → Set the "1."
 Rated output value
 Set it to Gain setting (GAI n).
 → Set the "1.234."

Linearizing type symbol table

Set value	Linearizing type symbol	Set value	Linearizing type symbol	Set value	Linearizing type symbol
0	No symbol	7	J	14	S
1	C	8	K	15	T
2	D	9	L	16	U
3	E	10	M	17	V
4	F	11	P	18	W
5	G	12	Q	19	X
6	H	13	R	20	Y

The rated output value (mV/V) of the CZ-100P/CZ-200P is when the cable is at a length of 5 m. When the cable is extended or a cable of a different manufacturer is used, the gain value must be corrected and changed.
 For details, refer to the CZ-100P/PCT-300 Resin Pressure Measuring System Instruction Manual (IM100CZ04-E□) or CZ-200P Instruction Manual (IM100CZ08-E□).

Symbol	Name	Data range	Description	Factory set value
P_b (Pb)	PV bias	-Input span to +Input span Varies with the setting of the Input decimal point position.	PV bias adds bias to the Measured value (PV). Manual zero adjustment can be performed.	0
dF (dF)	PV digital filter	0.1 to 100.0 seconds OFF: Unused	This item is the time of the first-order lag filter eliminate noise against the measured input.	OFF
P_r (Pr)	PV ratio	0.500 to 1.500 The setting value varies depending on using pressure sensor. Refer to ● PV ratio.	PV ratio is a multiplier to be applied to the Measured value (PV). Manual full scale adjustment can be performed.	1.000
ADD (Add)	Device address			
bPS (bPS)	Communication speed		This parameter is displayed when there is the communication function [Optional].	
$bI\Gamma$ (bIT)	Data bit configuration		Refer to the PG500 Communication Quick Instruction Manual (IMR02F03-EC) .	
$I n\Gamma$ (InT)	Interval time			
LCK (LCK)	Set lock level	0: Unlock 1: Lock Set to "0" or "1" for each digit.	The set lock level restricts parameter setting changes by key operation (Set data lock function).	0000
			Parameters of Setup Setting Mode and Parameter Setting Mode other than alarm set value (AL1 to AL4) (except for parameters in Engineering Mode). Alarm set value (AL1 to AL4) only "0" Fixed (Do not change this one) "1" Fixed (Do not change this one)	

- **PV ratio**
[When using our CZ-100P or CZ-200P]
- Explosionproof specification type
Set the desired correction factor of our safety barrier RZB-001 to the PV ratio. Thus, an indicated error caused by the use of the safety barrier is corrected. The correction factor is described in the nameplate attached to the safety barrier (RZB-001).
 - Non-explosionproof specification type
As the PV ratio, use a factory set value of "1.000" with this value left intact.
- [When using resistance for sensitivity adjustment built-in pressure sensor]
- The result obtained by auto calibration is reflected to the PV ratio. Manual full scale adjustment can be performed by changing this PV ratio value.

4.3 Parameter Setting Mode

Symbol	Name	Data range	Description	Factory set value
AZE (AZEr)	Auto zero *	-5.0 to +5.0 mV (Input conversion)	Adjust the zero point of the Measured value (PV). Refer to ● Auto zero.	—
$ACAL$ (ACAL)	Auto calibration	—	Adjust the full scale point of the Measured value (PV). Refer to ● Auto calibration.	—
$HLdr$ (HLdr)	Hold reset *	—	Peak hold/bottom hold value is reset.	—
ILr (ILr)	Interlock release *	—	If the alarm state is interlocked, interlock can be released. The interlock states of all alarms are released.	—
$AL1$ (AL1)	Alarm 1 set value (AL1)	Pressure display low to Pressure display high	Use to set the set value of the alarm action.	50
$AL2$ (AL2)	Alarm 2 set value (AL2)	This parameter is not displayed when the alarm type is set to "0: None."	Signals are output from the alarm outputs (ALM1 to ALM4) if exceeding the alarm set value.	0
$AL3$ (AL3)	Alarm 3 set value (AL3)			50
$AL4$ (AL4)	Alarm 4 set value (AL4)			50


* The auto zero, hold reset and interlock release functions can be executed by turning on the digital input.
D11 (Terminal Nos. 13 and 14): Auto zero D12 (Terminal Nos. 13 and 15): Hold reset
D13 (Terminal Nos. 13 and 16): Interlock release

For the digital input, refer to the **PG500 Installation Manual (IMR02F01-EC)**.

● Auto zero

Auto zero is used to automatically set the PV bias (Pb) so that the Measured value (PV) will be 0.

- Make sure that the pressure sensor is installed on the equipment.
- Rise the temperature of the equipment installed with the pressure sensor up to the temperature during operation.
- Set the pressure sensor to the no-load state.
- Press the UP key while pressing the DOWN key displaying the Auto zero screen automatically starts auto zero operation. If this auto zero operation normally end, the screen returns to the Measured value (PV) screen.




- If error occur, the "RSEr" and "Err" are displayed alternately on the PV display unit. Press any of the keys (SET key, <MONI key, DOWN key or UP key) to clear the error and return to the Measured value (PV) screen.
- The result of auto zero adjustment is also reflected to the PV bias (Pb) value. Manual zero point adjustment can be performed by changing this PV bias value. The auto zero can be executed by digital input 1 (DI1, terminal Nos. 13 and 14).

● Auto calibration (Only resistance for sensitivity adjustment built-in pressure sensor)

Auto calibration is used to automatically set the PV ratio (Pr) so that the Measured value (PV) will be the pressure of the Shunt resistance output value (SHNT).

- Make sure that the pressure sensor (resistance for sensitivity adjustment built-in pressure sensor) is installed on the equipment.
- Rise the temperature of the equipment installed with the pressure sensor up to the temperature during operation.
- Press the UP key while pressing the DOWN key displaying the Auto calibration screen automatically starts auto calibration operation. If this auto calibration operation normally end, the screen returns to the Measured value (PV) screen.



- If error occur, the "ACAL" and "Err" are displayed alternately on the PV display unit. Press any of the keys (SET key, <MONI key, DOWN key or UP key) to clear the error and return to the Measured value (PV) screen.
- For this product, in order to generate the R-cal output it is not necessary to short the cables (CAL+ and CAL-) on the pressure sensor side.
- The result obtained by auto calibration is reflected to the PV ratio value. Manual full scale point adjustment can be performed by changing this PV ratio value.

4.4 Engineering Mode

WARNING

Parameters in the Engineering mode (F10 to F91) should be set according to the application before setting any parameter related to operation. Once the Parameters in the Engineering mode are set correctly, no further changes need to be made to parameters for the same application under normal conditions. If they are changed unnecessarily, it may result in malfunction or failure of the instrument. RKC will not bear any responsibility for malfunction or failure as a result of improper changes in the Engineering mode.

All parameters of the engineering mode are displayed regardless of the instrument specification.

Symbol	Name	Data range	Description	Factory set value
$F10$ (F10)	Function block 10	This is the first parameter symbol of function block 10.		
$dSPT$ (dSPT)	Display timer	0.1 to 10.0 seconds	Use to set the time during which the displayed value is changed.	0.1
$dSoP$ (dSoP)	PV display condition	0 to 63 (Decimal) Bit 0: Minus display of PV value Bit 1: Input error * Bit 2: Alarm 1 occurs Bit 3: Alarm 2 occurs Bit 4: Alarm 3 occurs Bit 5: Alarm 4 occurs Data Bit 0 0: Minus display 1: Non-minus display Bit 1 to Bit 5 0: Non-flashing display 1: Flashing display	Sets the condition for flashing display of the Measured value (PV) and minus display of the Measured value (PV). When an alarm occurs and flashing is enabled, the Measured value (PV) and alarm number are alternately displayed.	0
			Bit data 000000 Bit 5.....Bit 0 Set the bit data after converting it to decimal.	

* When flashing is enabled, the Measured value (PV) flashes at the following times:
● Measured value (PV) exceeds the pressure display high/low.
● Measured value (PV) exceeds the input error determination point (high/low limit).

Symbol	Name	Data range	Description	Factory set value
$F21$ (F21)	Function block 21	This is the first parameter symbol of function block 21.		
$SHnT$ (SHnT)	Shunt resistance output value	40.0 to 100.0 % This parameter is valid when using resistance for sensitivity adjustment built-in pressure sensor.	It is set "What percentage of the rated output" is output when the full scale point of the Measured value (PV) is adjusted by auto calibration.	80.0
PoH (PoV)	Input error determination point (high) ¹		If the Measured value (PV) is above the Input error determination point (high), alarm action at input error will be taken.	53
PUn (PUn)	Input error determination point (low) ¹		If the Measured value (PV) is below the Input error determination point (low), alarm action at input error will be taken.	-2
$brES$ (brKS)	Burnout direction ²	0: Upscale 1: Downscale	Use to select burnout direction in input break.	0
GdP (GdP)	Gain setting decimal point position	3: Three decimal places 4: Four decimal places	Use to select the decimal point position of the gain setting value.	3
$F33$ (F33)	Function block 33	This is the first parameter symbol of function block 33.		
AHS (AHS)	Transmission output scale high ¹		Use to set a scale high limit value of the transmission output.	50
ALS (ALS)	Transmission output scale low ¹		Use to set a scale low limit value of the transmission output.	0
AOt (AOt)	Transmission output timer	0.1 to 10.0 seconds	Use to set the time during which the transmission output value is changed.	0.1
$F41$ (F41)	Function block 41	This is the first parameter symbol of function block 41 to 44.		
$F42$ (F42)	Function block 42	F41: Parameters of alarm 1 F43: Parameters of alarm 3 F42: Parameters of alarm 2 F44: Parameters of alarm 4		
$AS1$ (AS1)	Alarm 1 type	0: None 1: Process high 2: Process low	Use to select the action type of the alarm.	Based on model code ³
$AS4$ (AS4)	Alarm 4 type			
$AHo1$ (AHo1)	Alarm 1 hold action	0: OFF 1: Hold action ON	Use to select the hold action for the alarm.	Based on model code ³
$AHo4$ (AHo4)	Alarm 4 hold action			
$ILS1$ (ILS1)	Alarm 1 interlock	0: Unused (OFF) 1: Used	Use to select the interlock function for the alarm.	0
$ILS4$ (ILS4)	Alarm 4 interlock			
$EXC1$ (EXC1)	Alarm 1 energized/de-energized	0: Energized 1: De-energized	Use to select the alarm energized or de-energized.	0
$EXC4$ (EXC4)	Alarm 4 energized/de-energized			
$AH1$ (AH1)	Alarm 1 differential gap	0 to Input span	Use to set a differential gap of the alarm.	2
$AH4$ (AH4)	Alarm 4 differential gap			
$ALT1$ (ALT1)	Alarm 1 delay timer ¹	0.0 to 600.0 seconds	Alarm delay timer is to set an output delay time for alarm outputs	0.0
$ALT4$ (ALT4)	Alarm 4 delay timer ¹			
$AEo1$ (AEo1)	Alarm 1 action at input error	0: Normal alarm action 1: Forced alarm ON when temperature measured value exceeds the input error determination point (high or low limit).	Alarm action at input error is to select the alarm action when the Measured value (PV) reaches the input error determination point (high or low limit).	0
$AEo4$ (AEo4)	Alarm 4 action at input error			
$F60$ (F60)	Function block 60	This is the first parameter symbol of function block 60.		
CMP (CMP)	Communication protocol	0: RKC communication 1: Modbus	Use to select a protocol of communication function.	0
$F91$ (F91)	Function block 91	This is the first parameter symbol of function block 91.		
$C448$ (C448)	ROM version monitor	0 to 999 (C448-□□□)	Displays the version of the ROM on the instrument.	—

¹ Varies with the setting of the Input decimal point position.


² Setting of a barn out direction select switch is necessary to select a burnout direction. For the switch setting, refer to the **PG500 Installation Manual (IMR02F01-EC)**.

³ When not specifying: Alarm 1: Process high (without hold action) Alarm 3: No alarm
Alarm 2: Process low (without hold action) Alarm 4: No alarm

Symbol	Name	Data range	Description	Factory set value
$\int \Gamma$ (WT)	Integrated operating time monitor	0 to 19999 hours	Displays the integrated total operating time of the instrument.	—

■ Alarm function [Optional]

Action: When the Measured value (PV) reaches the alarm set value, alarm ON occurs.



● **Alarm hold action**
When hold action is ON, the alarm action is suppressed at start-up (Power ON) until the measured value has entered the non-alarm range.

● **Alarm interlock**
The alarm interlock function is used to hold the alarm state even if the Measured value (PV) is out of the alarm area after its entry into the area once.


● **Alarm differential gap**
It prevents chattering of alarm output due to the measured value fluctuation around the alarm set value.

● **Alarm delay timer**
When an alarm condition becomes ON status, the output is suppressed until the delay timer set time elapses. After the time is up, if the alarm output is still ON status, the output will be produced.

■ Transmission output function (AO) [Optional]

The transmission output function is used to output any Measured value (PV) as the voltage/current output. In addition, any range of the Measured value (PV) can be output with the transmission output scale low and transmission output scale high set.

Example: When a Measured value (PV) of 10 to 30 MPa needs to be recorded on a recorder at an pressure range of 0 to 50 MPa.
Output type: Current output, 4 to 20 mA DC
Transmission output scale high (AHS): 30 MPa
Transmission output scale low (ALS): 10 MPa



For the Transmission output (AO) type (rating, output range), refer to **PG500 Installation Manual (IMR02F01-EC)**.

5. ERROR DISPLAYS

■ Display when input error occurs

Prior to replacing the sensor, always turn OFF the power.

Display	Description	Action (Output)	Solution
PV [Flashing] *	PV exceeds the Pressure display high/low.	Output depending on the alarm action at input error	Check input type, input range, sensor and sensor connection.
	PV exceeds the input error determination point (high/low limit).		
■■■■ [Flashing]	Flashes when any of Alarms 1 to 4 has occurred. (The PV and alarm number are displayed alternately)	Output depending on the normal alarm action	
■■■■ [Flashing]	Over-scale PV is above the Pressure display high + (5 % of input span).	Output depending on the alarm action at input error	
■■■■ [Flashing]	Underscale PV is below the Pressure display low - (5 % of input span)	Output depending on the alarm action at input error	

* The PV flashes depending on the PV display condition (dSoP) of engineering mode F10.

■ Self-diagnostic error

In an error is detected by the self-diagnostic function, the "Err" and error code are displayed alternately on the PV display unit. If two or more errors occur simultaneously, the total summation of these error codes is displayed.

Solution: Turn off the power at once. If an error occurs after the power is turned on again, please contact RKC sales office or the agent.

PV display	Description	Action
1	Adjustment data error	Display: Error display (Err and error number) Output: All the output is OFF (Same as power OFF)
2	Back-up error	
4	A/D conversion error	
128	Watchdog timer error	Communication: Send the error code
256	Program error (stack)	
2048	Program error (busy)	
All display is OFF	Power supply voltage monitoring error	Display: All display is OFF Output: All output OFF
	RAM check error	Communication: Stop