




- ***Multi-input type selectable***
- ***Multi-dialog alarm function***
- ***Cooling fan malfunction detection***
- ***Auto output or manual output selectable***
- ***High and low output limit settable***
- ***Soft-start / kick start time settable***
- ***Power frequency 50/60Hz auto-detect***
- ***Zero cross control or phase control selectable***

◆ Function setting

Press Set Key and then ↓ (Down Key); hold both keys for 3 Seconds

Status	Symbol	Description
Running status 	 	1> Running status / 2> 「A」 : Output volume / 3> 「i」 : Output current volume (0.0~i) / 4> 「n」 : Manual output volume / 1> 「Lck=0」 : All lock / 2> 「Lck=1」 : Data settable / 3> 「Lck=2」 : Unlock / 1> 「A」 : Output volume (0~100%) / 2> 「i」 : Output current volume (0.0~i) / 3> 「n」 : Manual output volume (0~100%) / 1> Input type selection : Int.0 ~ Int.6 2> 「Int.0」 = [4 ~ 20mA] ; 「Int.1」 = [0 ~ 20 mA] ; 「Int.2」 = [1 ~ 5V] 「Int.3」 = [2 ~ 10V] ; 「Int.4」 = [0 ~ 5V] ; 「Int.5」 = [0 ~ 10V] 「Int.6」 = Variable resistance (10kΩ) / 1> 「Con.0」 : Zero cross control / 2> 「Con.1」 : Phase control / 1> 「Str.0」 = Soft start / 2> 「Str.1」 = Kick start /

◆ Data setting /

Press Set Key; hold for 3 Seconds


Status /	Symbol /	Description /
Volume of Output or input 	 	1> Running status / 2> 「A」 : Output volume / 3> 「i」 : Output current volume (0.0~i) / 4> 「n」 : Manual output volume / 1> Range : 0 ~ 100 2> Min. output volume setting / 1> Range : 0 ~ 199 2> Max. output volume setting / 1> Range : 0.0~99.9 2> Max. load current setting / 1> Range : 0 ~ 199 sec 2> Time of soft start / Time of kick start / 1> Range : - 99 ~ 99 2> Setting of Input offset /

Additional Items:


d.099 : When the Output Volume is > d.0nn, It Starts The Soft Start Function

ALn.O → Alarm output status is Normally Open (NO); ALn.1 → Alarm output status is Normally Closed (NC)


EPS2-40 / EPS2-60	TPS3-40 / TPS3-60 / TPS3-80
-------------------	-----------------------------




EPS2-80	EPS2-100 / EPS3-40 / EPS3-60 / EPS3-80	TPS3-100	TPS3-125 / TPS3-160 / TPS3-200
---------	--	----------	--------------------------------





EPS2-150	EPS □ □ □ □
----------	-------------




TPS □ □ □ □




◆ Type of Control Method

Control Method	Phase angle control	Zero cross control
Output volume		
		
		
		
Feature	1. Suited to control the inductive load or The variable resistance load (IR, Pure metal heater, Silicone carbonate heater or Transformer) 2. The power factor $\cos\theta < 1$ 3. Higher harmonic noise	1. Suited to control the constant resistance load or The capacity load. (Alloy heater or Capacitor) 2. The power factor $\cos\theta = 1$ 3. Lower harmonic noise


◆ Soft start /




◆ Kick start /



◆ Setting of manual output /

Manual output status	Description
	1. On the 「manual」 output status, Press Δ or ∇ key to change the manual output volume 2. Press [SET] to finish setting

◆ Setting of output limit /



Note :

- 1> 「Un」 : Output ratio
- 2> Setting range : Low limit = 0 ~ 100% , High limit = 0 ~ 199% /
- 3> Low + high limit setting is suited to control the radial heating heater such as IR lamp.

◆ Multi-input type /

- * [Int.0] : 4 ~ 20 mA * [Int.1] : 0 ~ 20 Ma * [Int.2] : 1 ~ 5 V * [Int.3] : 2 ~ 10 V
- * [Int.4] : 0 ~ 5 V * [Int.5] : 0 ~ 10 V * [Int.6] : VR / 10K Ω (103KB)

◆ External limit for output volume 【EPS & TPS series】

Please use a Variable resistance (10k Ω /103KB) to adjust the maximum output volume.
(10k Ω /103KB)

◆ Trouble shooting /

Alarm	Description /	Checking /
【nPEr】	Fuse break or phase loss	Please check load or power supply
【FnEr】	Cooling fan malfunction	Please check the cooling fan
【OhEr】	Over heat (120°C)	Please improve cooling condition

◆ Notice of safety /

 Warning	Potentially hazardous situation, if mishandling, may result in death or serious injury.
--	---

- 1) Please confirm the input type and connection method with this controller,
if not, it may result in malfunction.
- 2) Please do not touch any terminal of this controller while power supply is supplied,
if do, it may result in electronic shock.
- 3) 「Power supply system」 must to be shutdown before renew the fuse,
if not, it may result in electronic shock.
- 4) Please rated the load current within the specified value,
if not, it may result to burn up this controller or fuse.
- 5) Please tighten the screw terminal over 100kg-cm,
if not, it may result to burn up this controller or fuse.
- 6) If this controller is burned up, it may be in short circuit condition or malfunction,
please settle an independent alarm system to ensure safety protection,
if not, it may result in a serious accident.

Specifications may be modified without
notice in advance.